

## At A Glance

- No adhesives, screws or nails needed for installation
- No sanding or finishing required
- Installs directly over a concrete slab with a vapor barrier
- Transportable
- Real oak hardwood for Encore
- Real maple hardwood for Encore Elite
- Seamless appearance



Encore Elite  
Patented Click-And-Lock System



Encore Home

## Encore Wood Flooring Collection

Exceptional real hardwood design combines form and function. **Encore** is the revolutionary “click-and-lock” transportable hardwood floor with a factory finish and an integrated sprung subfloor. Recommended for virtually all activities including tap, jazz, contemporary, ballroom, and multi-purpose use. **Encore Elite** uses maple hardwood for a harder, more durable surface. **FloorShield II** is recommended for ballet and for easier cleaning of tap shoe residue. (See page 25.)

### ENCORE


<b>Price</b>	See insert or website for current pricing
<b>Panel Width</b>	7.875" (200 mm)
<b>Panel Length</b>	95.25" (2.42 lm)
<b>Thickness</b>	1.32" (33 mm)
<b>Weight</b>	11.5 lbs./panel (5.2 kg/panel)
<b>Square ft./Panel</b>	5.22 sq. ft.
<b>Material</b>	Oak   Integrated floating subfloor
<b>Life Expectancy</b>	Up to 10–15 years
<b>Guarantee</b>	1 year manufacturer defect

### ENCORE ELITE

<b>Price</b>	See insert or website for current pricing
<b>Panel Width</b>	7.875" (200 mm)
<b>Panel Length</b>	95.25" (2.42 lm)
<b>Thickness</b>	1.32" (33 mm)
<b>Weight</b>	11.5 lbs./panel (5.2 kg/panel)
<b>Square ft./Panel</b>	5.22 sq. ft.
<b>Material</b>	Maple   Integrated floating subfloor
<b>Life Expectancy</b>	Up to 10–15 years
<b>Guarantee</b>	1 year manufacturer defect

**STORAGE** Wood panels should be stored flat on a skid of equal or greater dimension in a climate controlled environment.

### Encore



Color: Oak

**NOTICE FOR ENCORE WOOD FLOORING:**  
Prices do not include shipping & handling. Please contact **Stagestep** for shipping & handling quotes.

See insert for prices in USD which are subject to change without notice. Latest pricing can be found on the website, [stagestep.com](http://stagestep.com)

INFORMATION ABOUT INSTALLATION AND MAINTENANCE IS PUBLISHED ON OUR WEBSITE